

Installation with Epicenter Overview

[Click the Part #'s below for more information.](#)

- 1** Place and Level Pedestals Part #2351736
- 2** Attach filler strips (if specified) Part #2338469
- 3** Build up Epicenters Part #2517770
- 4** Gang Epicenters Part #2517770
- 5** Insert Modesty Panels Part #2508082
- 6** Attach Epicenters to supporting structure and level entire station. This includes:
 - Metal Bases Part #2422090, 2445496, 2439932, 2439937
 - End Panels Part #2439928, 2439930
 - Mid Support Panels Part #2518048
 - End Support Panels Part #2517975
 - Universal Brackets Part #2382444
 - Stretcher of pedestal to lower Epicenter Part #2517770
- 7** Run power entry whip. Hint: In Single Sided applications, it may be easier to set up the minimum amount of bases to get the Epicenter to stand up alone, run the whip, and then attach the rest of the supporting structures.
- 8** Attach power entry whip and jumpers (if needed)
- 9** Attach communication lines
- 10** Attach end trim Part #2508075
- 11** Install receptacles
- 12** Insert upper epicenter inserts and attach blinders if necessary Part #2508094, #2508070
- 13** Install receptacle faceplates
- 14** Install blinders on full height inserts and then hang full height inserts Part #2508094, #2513735, #2516171
- 15** Install top cap Part #2508095
- 16** Install worksurfaces including worksurfaces coming off slat wall Part #2338468
- 17** Install overheads Part #2520956, 2520812