
SEATING

Loosen each caster nut by using a 9/16" open end wrench.

Unscrew casters from the bottom of the legs.



Assembly Instructions

CINCH® Soft Caster Replacement

Recommended Tools

• 9/16" Open End Wrench

Screw in the soft caster replacements. Tighten each caster nut by using a 9/16" open end wrench.

Package Contents Per Chair

Qty.

• Soft Casters (part #1979071)

NATIONAL

urniture with Personality™

Telephone 800.482.1717 Fax 812.482.8800 www.nationalonline.com

Part # 1991394

© 2006 Kimball International, Inc.