

**Products compatible with EPA Approved Disinfectants for use against SARS-CoV-2 (COVID-19)**

The following charts provide guidance on disinfectants that can safely be used on Designtex materials and meet the EPA's criteria for use against SARS-CoV-2 (the virus that causes COVID-19).

**How does the EPA know that these disinfectants work against SARS-CoV-2?**

While surface disinfectant products on [EPA's List N](#) have not been tested specifically against SARS-CoV-2, the EPA expects them to kill the virus because they:

- Demonstrate efficacy (e.g. effectiveness against a harder-to-kill virus); or
- Demonstrate efficacy against another type of human coronavirus similar to SARS-CoV-2.

Because SARS-CoV-2 is a new virus, this pathogen is not readily available for use in commercial laboratory testing to see if a certain disinfectant product is effective at killing the virus. The EPA's Frequent Questions about Disinfectants and SARS-CoV 2 (COVID-19) can be found [here](#).

The information in this guide refers to the performance of these disinfectants in tests conducted under laboratory conditions on the materials listed. This information is not guaranteed and does not relieve the user from the proper and safe use of referenced disinfecting agents. The disinfectants recommended here are not a comprehensive list. This list also does not include all Designtex products. Additional disinfectants can be screened against additional Designtex materials upon request.

For a step-by-step method for cleaning and disinfecting surface materials, please scroll to the end of this document.

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Architectural Finishes

Disinfectant	Bleach 1:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
<b>3M DI NOC</b>	•	•	•	•	•	•	•	•	•
<b>PolyVision Ceramic Steel</b>						•		•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

**Panel \***

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
<b>Clew</b>	•	•	•	•	•	•	•	•	•
<b>Decibel</b>	•	•	•	•	•	•	•	•	•
<b>Everywhere Texture</b>	•	•	•	•	•	•	•	•	•
<b>Gravity</b>	•	•	•	•	•	•	•	•	•
<b>Plateau</b>	•	•	•	•	•	•	•	•	•
<b>Velocity</b>	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Coated

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Air	•	•	•	•	•	•	•	•	•
Alcazar	•	•	•	•		•		•	•
Alchemy	•	•	•	•	•	•	•	•	•
Annex	•	•	•	•	•	•	•	•	•
Aspect	•	•	•	•		•	•	•	•
Beguiled By The Wild	•	•	•	•	•	•		•	•
Big Dot	•	•	•	•	•	•		•	•
Crosshatch	•	•	•	•		•	•		•
Crosswind	•	•	•	•	•	•	•	•	•
Current	•	•	•	•	•	•	•	•	•
Encircle	•	•	•	•	•	•	•	•	•
Faux Sure	•	•	•	•		•	•		•
Florin	•	•	•	•	•	•	•	•	•
Forestbound	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Coated

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Friendly Faux	•	•	•	•		•	•	-	•
Gale	•	•	•	•	•	•	•	•	•
Hyde	•	•	•	•		•		•	•
Inside Edge	•	•	•	•	•	•	•	•	•
Interlock	•	•	•	•	•	•		•	•
Interlude	•	•	•	•		•		•	•
Keen	•	•	•	•	•	•	•	•	•
Kindred	•	•	•	•	•	•	•	•	•
Leap	•	•	•	•	•	•	•	•	•
Leaves	•	•	•	•	•	•		•	•
Linnen	•	•	•	•	•	•	•	•	•
Little Dot	•	•	•	•	•	•		•	•
Luster	•	•	•	•	•	•		•	•
Metallo	•	•	•	•		•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Coated

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Metta	•	•	•	•	•	•	•	•	•
Microgrid	•	•	•	•	•	•	•	•	•
Migration	•	•	•	•		•	•		•
Pave	•	•	•	•	•	•	•	•	•
Pivot	•	•	•	•	•	•	•	•	•
Prime	•	•	•	•		•	•	•	•
Raia	•	•	•	•	•	•	•	•	•
Rainwater	•	•	•	•	•	•	•	•	•
Revelry	•	•	•	•		•		•	•
Rise	•	•	•	•		•		•	•
Rove	•					•			•
Rumeli	•	•	•	•	•	•	•	•	•
Sail	•	•	•	•	•	•	•	•	•
Shimmering Tide	•	•	•	•	-	•	•	-	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Coated

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Silicone Element	•	•	•	•	•	•	•	•	•
Silicone Element Celliant	•	•	•	•	•	•	•	•	•
Silicone Nappa	•	•	•	•	•	•	•	•	•
Sketch	•	•	•	•	•	•	•	•	•
Sorano	•	•	•	•	•	•	•	•	•
Spandau	•								•
Terra	•	•	•	•	•	•	•	•	•
Treeline	•	•	•	•	•	•	•	•	•
Trim	•	•	•	•	•	•	•	•	•
Trove	•	•	•	•		•		•	•
Vero	•	•	•	•	•	•	•	•	•
Vine	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Woven

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Acacia	•	•	•	•	•	•	•	•	•
Aloft	•	•	•	•	•	•	•	•	•
Angle	•	•	•	•	•	•	•	•	•
Anni	•	•	•	•	•	•	•	•	•
Atria	•	•	•	•	•	•	•	•	•
BitDrift	•	•	•	•	•	•	•	•	•
Boucle Dot	•	•	•	•	•	•	•	•	•
Building Blocks	•	•	•	•	•	•	•	•	•
Carom	•	•	•	•	•	•	•	•	•
Cassava	•	•	•	•	•	•	•	•	•
Circa	•	•	•	•	•	•	•	•	•
Circle Jacquard	•	•	•	•	•	•	•	•	•
Code	•	•	•	•	•	•	•	•	•
Concentric	•	•	•	•	•	•	•	•	•
Concept	•	•	•	•	•	•	•	•	•
Course	•	•	•	•	•	•	•	•	•



# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Woven

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
CrissCross	•	•	•	•	•	•	•	•	•
Cubitt	•	•	•	•	•	•	•	•	•
Dapple	•	•	•	•	•	•	•	•	•
Dart	•	•	•	•	•	•	•	•	•
Distressed Texture	•	•	•	•	•	•	•	•	•
Double Weave	•	•	•	•	•	•	•	•	•
Draft	•	•	•	•	•	•	•	•	•
Ellipsis	•	•	•	•	•	•	•	•	•
Everywhere Texture	•	•	•	•	•	•	•	•	•
Five Cities	•	•	•	•	•	•	•	•	•
Flow	•	•	•	•	•	•	•	•	•
Fluent	•	•	•	•	•	•	•	•	•
Geometric II	•	•	•	•	•	•	•	•	•
Gleam	•	•	•	•	•	•	•	•	•
Hatchmark	•	•	•	•	•	•	•	•	•
Hexstripe	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Woven

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Hint	•	•	•	•	•	•	•	•	•
Ink	•	•	•	•	•	•	•	•	•
Jacquard I	•	•	•	•	•	•	•	•	•
Jaunt	•	•	•	•	•	•	•	•	•
Josef	•	•	•	•	•	•	•	•	•
Latitude	•	•	•	•	•	•	•	•	•
Lattice	•	•	•	•	•	•	•	•	•
Line Variations	•	•	•	•	•	•	•	•	•
Mark	•	•	•	•	•	•	•	•	•
Mod	•	•	•	•	•	•	•	•	•
Modern Tweed	•	•	•	•	•	•	•	•	•
Motif	•	•	•	•	•	•	•	•	•
Mountainous	•	•	•	•	•	•	•	•	•
Net	•	•	•	•	•	•	•	•	•
Oxford Stripe	•	•	•	•	•	•	•	•	•
Pause	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Woven

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Pennant	•	•	•	•	•	•	•	•	•
Pennant Celliant	•	•	•	•	•	•	•	•	•
Pennington	•	•	•	•	•	•	•	•	•
Phenomena	•	•	•	•	•	•	•	•	•
Pinball	•	•	•	•	•	•	•	•	•
Pinpoint	•	•	•	•	•	•	•	•	•
Pixel Cloud	•	•	•	•	•	•	•	•	•
Plaid	•	•	•	•	•	•	•	•	•
Pleat	•	•	•	•	•	•	•	•	•
Plexus	•	•	•	•	•	•	•	•	•
Pop Art	•	•	•	•	•	•	•	•	•
Posey	•	•	•	•	•	•	•	•	•
Prompt	•	•	•	•	•	•	•	•	•
Queue	•	•	•	•	•	•	•	•	•
Rail	•	•	•	•	•	•	•	•	•
Rotary	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Upholstery Woven

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Round Leaves	•	•	•	•	•	•	•	•	•
Savile Plaid	•	•	•	•	•	•	•	•	•
Scale	•	•	•	•	•	•	•	•	•
Schism	•	•	•	•	•	•	•	•	•
Sense	•	•	•	•	•	•	•	•	•
Shibori Stripe	•	•	•	•	•	•	•	•	•
Shortcut	•	•	•	•	•	•	•	•	•
Social Dance	•	•	•	•	•	•	•	•	•
Span	•	•	•	•	•	•	•	•	•
Splice	•	•	•	•	•	•	•	•	•
Split	•	•	•	•	•	•	•	•	•
Sprint	•	•	•	•	•	•	•	•	•
Stratum	•	•	•	•	•	•	•	•	•
Striae	•	•	•	•	•	•	•	•	•
Stride	•	•	•	•	•	•	•	•	•
Subtle	•	•	•	•	•	•	•	•	•

Product and Disinfectant List  
SARS-CoV-2 (COVID-19)

Upholstery Woven

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Sunburst	•	•	•	•	•	•	•	•	•
Swing	•	•	•	•	•	•	•	•	•
System	•	•	•	•	•	•	•	•	•
Tap	•	•	•	•	•	•	•	•	•
Tramway	•	•	•	•	•	•	•	•	•
Tumbleweed	•	•	•	•	•	•	•	•	•
Turn	•	•	•	•	•	•	•	•	•
Urban Grid	•	•	•	•	•	•	•	•	•
Whim	•	•	•	•	•	•	•	•	•
Windowpane Crypton	•	•	•	•	•	•	•	•	•
Woodcut	•	•	•	•	•	•	•	•	•

# Product and Disinfectant List

## SARS-CoV-2 (COVID-19)

### Wallcovering

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Atmosphere	•	•	•	•	•	•	•	•	•
Baseline	•	•	•	•	•	•	•	•	•
Binary	•	•	•	•	•	•	•	•	•
Bisect	•								•
Biwa	•								•
Blink	•								•
Cambric	•								•
Chime	•								•
Chord	•								•
Colora	•								•
Fold	•								•
Glint	•								•
Hive	•								•
Linen Weave	•								•

Product and Disinfectant List  
SARS-CoV-2 (COVID-19)

Wallcovering

Disinfectant	Bleach 10:1	Oxivir® 1	Oxivir® 1 Wipes	Oxivir® Tb	OxyCide™	Sani-Cloth® AF3	Sani-Cloth® Bleach	Super Sani-Cloth®	Virex® II 256
EPA Registration No. Type	Various Sodium hypochlorite	70627-74 Hydrogen peroxide	70627-77 Hydrogen peroxide	70627-56 Hydrogen peroxide	Daily Disinfectant Cleaner 1677-237 Hydrogen peroxide, Peroxyacetic acid	Germicidal Disposable Wipe 9480-9 Quaternary ammonium	Germicidal Disposable Wipe 9480-8 Sodium hypochlorite	Germicidal Disposable Wipe 9480-4 Quaternary ammonium, Isopropanol	70627-24 Quaternary ammonium
Luma	•								•
Luxe	•								•
Madera	•								•
Ossetra	•								•
Plaid Weave	•								•
Prefab	•								•
Spark	•								•
Spectra	•								•
Tacit	•								•
Talula	•								•
Tephra	•								•
Timo	•								•
Tint	•								•

Cleaning and disinfecting are not the same; products that are used for soil and stain removal may not be effective disinfectants. Conversely, products that disinfect may not be effective for soil and stain removal.

### Cleaning Designtex Materials

Cleaning removes germs, dirt, and impurities from surfaces or objects. Cleaning works by using soap (or detergent) and water to physically remove germs from surfaces. This process does not necessarily kill germs, but by removing them, it lowers their numbers and the risk of spreading infection.

Cleaning is an important first step towards disinfecting. Cleaning removes organic material from the surface, enabling the disinfectant to act efficiently on the surface germs that are present on the material.

- It is important to follow appropriate cleaning methods and perform regular maintenance. Please see [Designtex's Cleaning Manual](#) for expanded details by product end use.
- Materials have cleaning codes of:
  - W (Water based only)
  - S (Solvent based only)
  - WS (Water and Solvent based)
  - WM (Water based/Crypton approved cleaners)
- Follow proper dilution of cleaners as instructed by the manufacturer.
- Common water-based cleaners are Ivory soap and water, and common solvents are 409 Multi-Purpose and Fantastik.
- Do not oversaturate the fabric; use small amounts of cleaning liquid at a time and blot between applications. Liquids should never be pressed through the fabric and care should be taken to not let liquids pool at the seams.
- All surfaces MUST be rinsed with water after cleaning.

### Using Disinfectants on Designtex Materials

Disinfecting refers to using chemicals, for example, EPA-registered disinfectants, to kill germs on surfaces. This process does not necessarily clean dirty surfaces or remove germs, but by killing germs on a surface after cleaning, it can further lower the risk of spreading infection.

- Always follow the manufacturer's dilution for use.
- Follow the recommended contact (dwell) time for your specific cleaner. The [EPA List N](#) for disinfectants against SARS-CoV-2 (COVID-19) includes recommended contact times. Note that manufacturer contact time recommendations may vary for disinfecting against different germs. For SARS-CoV-2 (COVID-19), follow the EPA contact times in List N.
- All surfaces MUST be rinsed with water after completing disinfection. Wipe dry.