


Assembly Instructions


WaveWorks® Metal Overhead Storage

1 **Note:** Remove the key by reaching through the back opening of the unit. **Figure A**

Locate lock clips installed in upper rear corners of overhead and remove them (Figure A).




2 Determine if overhead will be mounted over the tackboard, markerboard or slat wall inserts or directly to the wall. If over the inserts, remove the spacer by removing the four (4) screws (Figure B).



Recommended Tools


- Screwdriver

3 Attach brackets onto the overhead unit as shown in (Figure C), before putting anything on the wall.



Package Contents	Qty
• Unit	1
• Brackets	2
• Spacer	1
• #10 x 1/2" PHP SM Screw	4

4 Position lock clips so unnotched flange engages along side the second hook in rear brackets. Reinstall screw into each clip (Figure D).



Proper product installation, in accordance with these instructions, is the responsibility of the installing agent. If you have any questions concerning these instructions, please call National Customer Service.

NATIONAL

Furniture with Personality®

Telephone 800.482.1717
Fax 812.482.8800
www.NationalOfficeFurniture.com

Part # 2343737
Rev,A


Printed in U.S.A
© 2015 Kimball International, Inc.

Assembly Instructions

WaveWorks® Metal Overhead Storage


- 5** Using two (2) or more people, attach the overhead to the wall rail by tilting and engaging the brackets into the channel in the slot on top of the upper wall rail (Figure E).

Figure E




- 6** **Caution:** Inspect the brackets to ensure they are properly engaged over and under the wall rail (Figure F).

Figure F



- 7** Tilt overhead out slightly. Carefully slide support bar between overhead and tile until mounting plates are flush with bottom of overhead. Attach with four #10 x 1/2" screws provided. (Figure G).

Figure G



- 8** Tilt overhead out slightly and slide to final position.