

## Assembly Instruction

**1**

**Note:** Worksurface mounting bracket quantity:  
**Worksurface width/length**

Worksurfaces, less or equal to 48"  
 Greater than 48", less than or equal to 72"  
 Greater than 72"


**Brackets needed**

2  
 3  
 4


Brackets will be inset 1 1/2" from edge of worksurface or as close to the worksurface edge as possible without interfering with the flat brackets, undersurface storage or support legs.

**Note:** Worksurfaces can be mounted with worksurface brackets (Figure A) and supported with pedestals, end panels, and support bases (Figure B).

**Figure A**




**Figure B**



**2**

Insert hook on the worksurface bracket into the wall rail at an angle. Push the bracket downward allowing the bracket to hang off of the wall rail (Figure C). **Note:** The maximum span of an unsupported worksurface should not exceed 48" for 1 3/16" worksurfaces and 60" for 1 9/16" worksurfaces. Support is required within 6" of surfaces butted end-to-end. This may be a pedestal or a support panel.


**Figure C**



**3**

Place worksurface on clean, solid surface, back side facing up. Install the flat brackets on the main worksurface, approximately 2" from front edge and approximately 2" from back edge of the adjoining worksurface using the screws provided (Figure D). Ensure that the flat bracket does not interfere with other bracket or components. Two (2) flat bracket are required to join surfaces end-to-end or at a right angle.

**Figure D**



**Exhibit™**  
 Worksurface Bracket

**Recommended Tools**

- Screwdriver
- Tape Measure

Package Contents	Qty.
• Worksurface Bracket	Per Order
• # 8 x 1" Pan Head Screws	Per Order

**NATIONAL**

Furniture with Personality®

Telephone 800.482.1717  
 Fax 812.482.8800  
[www.NationalOfficeFurniture.com](http://www.NationalOfficeFurniture.com)

Part #2258949  
 Rev,-

Printed in U.S.A  
 © 2011 Kimball International, Inc.


Proper product installation, in accordance with these instructions, is the responsibility of the installing agent. If you have any questions concerning these instructions, please call National Customer Service.

## Assembly Instructions

### Worksurface Bracket


- 4** Lay worksurface onto brackets, and flush against the rail (Figure E).  
**Tip:** Use an undersurface component or other means to support the worksurface until the worksurface brackets are secured.

Figure E



- 5** Attach worksurface to the flat brackets with screws provided (Figure F). Eight screws total are required per bracket. Beginning at one end of the worksurface, apply pressure to the front of the worksurfaces while controlling the gaps between the rails and back edge of the worksurfaces.

Figure F



- 6** Attach the worksurfaces to the worksurface brackets using six (6) #8 x 1" Pan Head screws per bracket (Figure G).

Figure G

