

VORA TASK SEATING

ERGONOMIC FEATURES+ADJUSTMENTS

SWIVEL TILT CONTROL

PNEUMATIC LIFT

Raise or lower seat of chair to minimize pressure placed under thighs. At the correct seat height, feet should rest flat on the floor.

To ensure smooth operations, raise and lower your seat monthly.

To raise chair, pull lever down while lifting body off seat.

To lower chair, stay seated and pull lever down.

TILT LOCK

Locks tilt of chair to limit recline. Back can be locked in an upright position or be set to recline freely.

Push lever in to engage lock.

Pull lever out to disengage lock.

TENSION CONTROL

Increase or decrease tension of chair's tilt to match your body weight. Proper tension should allow you to lean back easily while providing balanced support when reclining.

Turn knob counterclockwise to increase tension.

Turn knob clockwise to reduce tension.



ARM HEIGHT*

Raise or lower arms to support forearms and keep shoulders in a neutral posture. Proper positioning reduces strain in the neck and shoulders.

To adjust arm height, press button on side of the arms while moving arm up or down.

Release button to lock in place.

SWIVEL TILT CONTROL MECHANISM

The swivel tilt control allows the seat and back to tilt in unison from a point at the center of the chair to comfortably recline.

ANSI/BIFMA ACCEPTANCE

Meets the ANSI/BIFMA X5.1-2017 general purpose office chair testing guidelines developed by the Business and Institutional Furniture Manufacturer's Association (BIFMA), and approved by the American National Standards Institute (ANSI).

*Your chair may not have all the features and adjustments shown. Please visit NationalOfficeFurniture.com for additional product information.

VORA TASK SEATING

ERGONOMIC FEATURES+ADJUSTMENTS

KNEE TILT CONTROL

PNEUMATIC LIFT

Raise or lower seat of chair to minimize pressure placed under thighs. At the correct seat height, feet should rest flat on the floor.

To ensure smooth operations, raise and lower your seat monthly.

To raise chair, pull lever up while lifting body off seat.

To lower chair, stay seated and pull lever up.

TENSION CONTROL

Increase or decrease tension of chair's tilt to match your body weight. Proper tension should allow you to lean back easily while providing balanced support when reclining.

Turn knob counterclockwise to increase tension.

Turn knob clockwise to reduce tension.



ARM HEIGHT*

Raise or lower arms to support forearms and keep shoulders in a neutral posture. Proper positioning reduces strain in the neck and shoulders.

To adjust arm height, press button on side of the arms while moving arm up or down.

Release button to lock in place.

TILT LOCK

Locks tilt of chair to limit recline. Back can be locked in an upright position or be set to recline freely.

Push lever down to engage lock.

Pull lever up to disengage lock.

KNEE TILT CONTROL MECHANISM

Knee tilt chairs provide full adjustment support for multiple tasks. The pivoting point is located near the very front of the seat, resulting in a wide-angle tilt that allows your feet to stay flat on the floor when the chair is tilted backward.

ANSI/BIFMA ACCEPTANCE

Meets the ANSI/BIFMA X5.1-2017 general purpose office chair testing guidelines developed by the Business and Institutional Furniture Manufacturer's Association (BIFMA), and approved by the American National Standards Institute (ANSI).

*Your chair may not have all the features and adjustments shown. Please visit NationalOfficeFurniture.com for additional product information.